





## **HU-FRIEDY PROCEDURAL SET-UP**

**BLACK LINE RUBBER DAM CLAMP KIT** 







How the best perform

## BLACK LINE RUBBER DAM CLAMP KIT





RDCM13AX Rubber Dam Clamp #13A, Black Line Serrated offset jaws for lower left molars; paired with RDCM12AX.



RDCM2AX
Rubber Dam Clamp #2A, Black Line
Flat jaws for larger premolars.



B RDCM12AX Rubber Dam Clamp #12A, Black Line Serrated offset jaws for lower right molars; paired with RDCM13X.



RDCM26X
Rubber Dam Clamp #26, Black Line
Slightly reversed festooned jaws for small lower
molars.



RDCM14X
Rubber Dam Clamp #14, Black Line
Deeply festooned jaws for partially erupted or irregularly shaped molars.



RDCOB
Rubber Dam Clamp Organizing Board
Rubber Dam Clamp Organizing Board holds up to
8 clamps during sterilization and fits into cassette accessory area.



RDCM27NX
Rubber Dam Clamp #27N, Black Line
Slightly festooned jaws for premolars.



RDCMW8AX
Rubber Dam Clamp #W8A, Black Line
Slightly festooned jaws for molars.



RDCM212X Rubber Dam Clamp #212, Black Line Flat jaws for labial caries on anterior teeth.



