INSTRUCTIONS FOR USE

Sterilization

Sani-Tube™ Nylon Sterilization Tubing

Instructions for use:

1. Cut tubing approximately 4" (10 cm) longer than the instrument(s) to be sterilized.
2. Heat seal one end of the tubing approximately 1" (2.5 cm) away from the opening, ensuring the seal is free of wrinkles or creasing.

   Follow sealer manufacturer's recommendations for heat sealing.
3. Carefully place the instrument(s) inside the tubing and remove any excess air.
4. Utilize internal and external dry heat chemical indicators and biological indicators in accordance with facility guidelines and local standards.
5. Ensure the tubing contents are a minimum of 1" (2.5 cm) away from all sides of the tubing.
6. Heat seal the open end of the tubing approximately 1" (2.5 cm) away from the opening, ensuring the seal is free of wrinkles or creasing.
7. Place sealed tubing flat in the sterilizer. Avoid any contact with metal trays or other tubing by inserting paper or cloth applicable for dry heat sterilization between tubing and between tray and tubing.
8. Follow directions for sterilization according to the manufacturer of the sterilizer.
9. Allow bags to cool in the sterilizer 5-10 minutes after cycle completion.

Ref.#'s SI2, SI3, SI4, SI6,
SN2, SN3, SN4, SN6

Do not reuse.

LATEX

Not made with natural rubber latex.

Crosstex International, Inc.
10 Ranick Road, Hauppauge, NY 11788-4209 USA
www.crosstex.com 800.276.7783 631.582.6777

EC REP MDSS GmbH
Schiffgraben 41
30175 Hannover, Germany

CE

Made in USA
SI/SN-IFU / REV A - 05/2020

All product names are trademarks of Crosstex International, Inc., a Cantel Medical Company, its affiliates or related companies, unless otherwise noted. Marks not registered in all jurisdictions.

CROSSTEX
A CANTEL MEDICAL COMPANY