

Governor Tony Evers

Dawn Crim, Secretary

Department of Safety and Professional Services Division of Industry Services Plumbing Product Review 4822 Madison Yards Way P.O. Box 7162 Madison, Wisconsin 53707-7162 Phone 608-266-2112 Web http://dsps.wi.gov Email dsps@wisconsin.gov TTY: Contact Through Relay

July 15, 2019

CROSSTEX INTERNATIONAL INC. CANTEL MEDICAL PABLO MARTINEZ 1733 PARKSIDE LANE PHOENIX AZ 85027

Re: Description:

HEALTH CARE PLUMBING APPLIANCE

Manufacturer:

CROSSTEX INTERNATIONAL INC. - CANTEL MEDICAL

Product Name:

VISTAPURE

Model Number(s): V3000, CVV3000 AND VISTAPURE 3000

eSLA ID No:

DIS 071903626

The specifications and/or plans for this plumbing product have been reviewed and determined to be in compliance with chapters SPS 382 through 384, Wisconsin Administrative Code, and Chapters 145 and 160, Wisconsin Statutes.

The Department hereby issues an approval based on the Wisconsin Statutes and the Wisconsin Administrative Code. This approval is valid until the end of July 2024.

This approval supersedes the approval issued on August 15, 2014 under product file number 20140246.

This approval is contingent upon compliance with the following stipulation(s):

- > These devices are intended to provide high purity water for various medical/clinical/laboratory equipment (e.g., autoclaves, dental bottles, ultrasonic cleaners, instrument washers, etc.) These devices are not intended for drinking water applications.
- Installation and maintenance of this product must be in accordance with the manufacturer's printed installation and maintenance instructions. A copy of the installation, operating and maintenance instructions shall be provided to each system owner and remain onsite.
- These devices shall be connected to municipal water supplies only.
- These devices shall discharge their wastewater to the drain system via an acceptable air gap (i.e. ASME A112.1.2 or ASME A112.1.3).
- > If these devices are directly connected to autoclave, ultrasonic cleaner, instrument washer, analyzer or similar devices, then a cross connection control device suitable for high hazard shall be placed between these devices and the equipment being served.
- The waterline serving the water dispensing wand shall be protected with cross connection control device suitable for high hazard.
- These devices shall be installed by properly licensed Wisconsin Plumbers.
- These devices shall be connected to cold water supplies only.
- If the water to these devices contains significant levels of dissolved hardness, iron, manganese or hydrogen sulfide, the pretreatment of the water is strongly advised.

SBD-10564-E (N.10/97) File Ref: DIS071903626.DOC Crosstex International Inc. – Cantel Medical

July 15, 2019 Page 2 of 2

eSLA ID No: DIS 071903626

The department is in no way endorsing this product or any advertising and is not responsible for any situation which may result from its use.

Sincerely,

Glen W. Schrüefer

Plumbing Product Reviewer

Department of Safety and Professional Services

Division of Industry Services Bureau of Technical Services (608) 267-1401 Phone

(608) 267-9723 Fax

glen.schlueter@wi.gov E-mail