EN

Sani-Tube™ Nylon Sterilization Tubing

REF SI2 / SI3 / SI4 / SI6 / SN2 / SN3 / SN4 / SN6

INSTRUCTIONS FOR USE

1. Cut tubing approximately 4 in (10 cm) longer than the instrument(s) to be sterilized.
2. Heat seal one end of the tubing approximately 1 in (2.5 cm) away from the opening, ensuring the seal is free of wrinkles or creasing.

   Follow sealer manufacturer's recommendations for heat sealing.
3. Carefully place the instrument(s) inside the tubing and remove any excess air.
4. Utilize internal and external dry heat chemical indicators and biological indicators in accordance with facility guidelines and local standards.
5. Ensure the tubing contents are a minimum of 1 in (2.5 cm) away from all sides of the tubing.
6. Heat seal the open end of the tubing approximately 1 in (2.5 cm) away from the opening, ensuring the seal is free of wrinkles or creasing.
7. Place sealed tubing flat in the sterilizer. Avoid any contact with metal trays or other tubing by inserting paper or cloth applicable for dry heat sterilization between tubing and between tray and tubing.
8. Follow directions for sterilization according to the manufacturer of the sterilizer.
9. Allow bags to cool in the sterilizer 5-10 minutes after cycle completion.



CROSSTEX
Crosstex International, Inc.
6789 W. Henrietta Road, Rush, NY 14543 USA
585.359.0130 | 631.582.6777 | crosstex.com

EC REP MDSS GmbH
Schiffgraben 41
30175 Hannover, Germany

CE

MD

Not made with natural rubber latex.

Made in USA
SI/SN-IFU-EN / REV A - 07/2021
All company and product names are trademarks of Hu-Friedy Mfg. Co., LLC, its affiliates or related companies, unless otherwise noted.
©2026 Hu-Friedy Mfg. Co., LLC. All rights reserved.

HuFriedyGroup
The Best In Practice